

Removal and Installation

Removal

1. Refer to: [Front Wheel Bearing and Wheel Hub](#) (204-01 Front Suspension, Removal and Installation).

Installation

1. To install, reverse the removal procedure.

mcx30.com