


### Removal and Installation

#### Removal


NOTE: Removal steps in this procedure may contain installation details.

1.




2. Refer to: [Jacking and Lifting](#) (100-02 Jacking and Lifting, Description and Operation).

3.



4. Refer to: [Floor Console](#) (501-12 Instrument Panel and Console, Removal and Installation).


5.




6.



7.



8.



### Installation

1. To install, reverse the removal procedure.
2. Refer to: [Parking Brake Cable Adjustment](#) (206-05 Parking Brake and Actuation, General Procedures).