


Engine Cooling - 2.0L EcoBlue (77kW/105PS) (YL)/2.0L EcoBlue (96kW/130PS) (YM)/2.0L EcoBlue (125kW/170PS) (YN) - Engine Cooling - Component Location


 Print

Description and Operation



E237071

Item	Description
1	Coolant hoses to heater core
2	Degas bottle
3	Radiator
4	EGR cooler bypass vacuum actuator
5	Thermostat housing (incorporating three-plate thermostat with electric heating element and ECT (engine coolant temperature) sensor)
6	Electric heating element connector
7	Engine oil cooler
8	EOP (engine oil pressure) sensor
9	EGR cooler
10	Coolant pump
11	Electrical coolant pump (supplies coolant to Diesel Exhaust Fluid (DEF) injector)



E237070

Item	Description
1	Electrical coolant pump (supplies coolant to Diesel Exhaust Fluid (DEF) injector)
2	Radiator
3	Coolant pump
4	Coolant pump rear housing
5	Coolant hoses to DEF injector