


## **Removal and Installation**

### **Removal**

NOTE: Removal steps in this procedure may contain installation details.

1. *Torque:* 8 Nm



### **Installation**

1. To install, reverse the removal procedure.