

Removal and Installation

General Equipment

Cable Ties

Removal

1. Refer to: [Main Control Cover](#) (307-01 Automatic Transmission, Removal and Installation).
- 2.



- 3.



Installation


1. Use the General Equipment: [Cable Ties](#)



- 2.



3. Torque: 12 Nm



4.



5. Refer to: [Main Control Cover](#) (307-01 Automatic Transmission, Removal and Installation).