


Removal and Installation

Removal




NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Diesel Fuel System Health and Safety Precautions](#) (100-00 General Information, Description and Operation).
2. Refer to: [Fuel Tank Draining](#) (310-00A Fuel System - General Information, General Procedures).
3.  NOTICE: Make sure that no strain is placed on the fuel lines and wiring harnesses.



4. Refer to: [Quick Release Coupling](#) (310-00A Fuel System - General Information, General Procedures).



E157652

5.



E157654

Installation

1. To install, reverse the removal procedure.