

General Procedures



Special Tool(s)

	412-134 Holding Tool, Compressor Clutch
---	--

Activation

1. Operate the air conditioning clutch several times with the aid of a 5 A fused cable. Refer to the relevant wiring diagram for the correct electrical connection. Check the gap A at 60° intervals around the circumference of the pulley.

Refer to: [Specifications](#) (412-00 Climate Control System - General Information, Specifications).




E92144

2. Use Special Service Tool: [412-134](#).



3. If necessary correct the gap A using only one spacer washers.



E68470

4. Refer to: [Specifications](#) (412-00 Climate Control System - General Information, Specifications).
Use *Special Service Tool*: [412-134](#).



5. Check the gap A as described in step 1. If necessary, repeat steps 2-5.

Refer to: [Specifications](#) (412-00 Climate Control System - General Information, Specifications).