


Removal and Installation

Materials

Name	Specification
Refrigerant Oil	WSH-M1C231-B

Removal

1. Refer to: [Air Conditioning \(A/C\) Compressor Manifold and Tube Assembly \(412-01 Climate Control, Removal and Installation\)](#).
- 2.



Installation

1.  **NOTICE:** Only use the specified material to lubricate the seals.
To install, reverse the removal procedure.

Material: [WSH-M1C231-B \(Refrigerant Oil\)](#)