


Removal and Installation

Materials

Name	Specification
Refrigerant Oil	WSH-M1C231-B

Removal

1. Refer to: [Thermostatic Expansion Valve Manifold and Tube Assembly](#) (412-01 Climate Control, Removal and Installation).
- 2.



E158914

Installation

1.  **NOTICE:** Only use the specified material to lubricate the seals.
To install, reverse the removal procedure.

Material: [WSH-M1C231-B \(Refrigerant Oil\)](#)