

Removal and Installation

Materials


Name	Specification
Refrigerant Oil	WSH-M1C231-B

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Climate Control System Health and Safety Precautions](#) (100-00 General Information, Description and Operation).
2. Refer to: [Jacking and Lifting](#) (100-02 Jacking and Lifting, Description and Operation).
3.  **WARNING:** Make sure that the high-pressure cutoff switch valve closes completely after removal of the high-pressure cutoff switch.

Torque: 8 Nm



Installation

1.  **NOTICE:** Only use the specified material to lubricate the seals.
To install, reverse the removal procedure.

Material: [WSH-M1C231-B \(Refrigerant Oil\)](#)