


Removal and Installation

Removal

1. Refer to: [Auxiliary Climate Control Housing](#) (412-02A Auxiliary Climate Control, Removal and Installation).
- 2.



E152005

- 3.



E152006

Installation

1. To install, reverse the removal procedure.

mcx30.com