


Removal and Installation

Removal

1. Refer to: [Headliner](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
- 2.



Installation

1. To install, reverse the removal procedure.