


Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Front Headliner - Bus](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
Refer to: [Front Headliner - Van](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
2. Torque: 3.2 Nm



Installation

1. To install, reverse the removal procedure.