


Removal and Installation


Removal

1.  **NOTICE:** Make sure that the brake pedal remains in the rest position.



Installation

1. **NOTE:** Make sure that the ignition key is in the OFF position.



2.  **NOTICE:** Make sure that the brake pedal remains in the rest position.

NOTE: Allow the brake pedal to return to it's natural off position, do not lift the brake pedal.

