

Removal and Installation

Removal


Vehicles with liftgate

1.




E152078

2.




E162128

3.




All vehicles

4. On both sides.



5. On both sides.



Installation

1. To install, reverse the removal procedure.