


Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Instrument Panel](#) (501-12 Instrument Panel and Console, Removal and Installation).
2. Torque: 12 Nm



3.

