


Removal

1. Refer to: [Instrument Panel](#) (501-12 Instrument Panel and Console, Removal and Installation).
2. Refer to: [Auxiliary Climate Control Housing](#) (412-02A Auxiliary Climate Control, Removal and Installation).
3. Refer to: [Front Headliner - Bus](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
Refer to: [Front Headliner - Van](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

4. Refer to: [Rear Headliner](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

5.





Installation

1. To install, reverse the removal procedure.