

Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.

Installation

1.  **NOTICE:** Make sure that the motor is in the park position.
To install, reverse the removal procedure.

mcx30.com