



Removal and Installation

Removal


1. Refer to: [Wheel and Tire](#) (204-04A Wheels and Tires, Removal and Installation).
2. Vehicles built up to 2015-07-31




3. Vehicles built from 2015-07-31




- 4.



- 5.



6.



Installation

1. To install, reverse the removal procedure.