

General Procedures

Adjustment


1. Refer to: [Body and Frame](#) (501-26 Body Repairs - Vehicle Specific Information and Tolerance Checks, Description and Operation).
2.
 1. **NOTE: Only tighten the bolts finger tight at this stage.**
Loosen:
2 turn(s)
 2. After operation check the alignment and correct if necessary.

Torque: 25 Nm



E183074

3.



E183075

4. After operation check the alignment and correct if necessary.



E183076