



Removal

NOTE: Removal steps in this procedure may contain installation details.


1.




2.



3. *Torque*: 35 Nm



4. 1. Torque: 10.5 Nm



Installation

1. To install, reverse the removal procedure.