


Removal and Installation

Removal


1. On both sides.



2. On both sides.




- 3.



Installation

1.



2. On both sides.



3. On both sides.

Torque: 24 Nm



4. After operation check the alignment and correct if necessary.

5. On both sides.



E185656

mcx30.com