

## Diagnosis and Testing

### General Equipment

Ford diagnostic equipment

Refer to Wiring Diagram Section 124-1 for schematic and connector information.

### Inspection and Verification

1. Verify the customer concern.
2. Visually inspect for obvious signs of mechanical or electrical damage.

### VISUAL INSPECTION CHART

| Mechanical                                                           | Electrical                                                                                                                                                                                                                                                                                                                      |
|----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"><li>• Exterior mirror(s)</li></ul> | <ul style="list-style-type: none"><li>• Fuse(s)</li><li>• Relay(s)</li><li>• Wiring harness</li><li>• Electrical connector(s)</li><li>• Exterior mirror control switch</li><li>• Exterior mirror(s)</li><li>• Auto dimming interior mirror</li><li>• Auxiliary junction box (AJB)</li><li>• Body control module (BCM)</li></ul> |

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
4. If the cause is not visually evident, refer to the [Ford diagnostic equipment](#) to diagnose the system.