


Removal and Installation

Special Tool(s)

	501-125 Remover, Grab Handle Cover
---	---------------------------------------

Removal

1. Use Special Service Tool: [501-125](#).



Installation

1. To install, reverse the removal procedure.