

Removal and Installation


General Equipment

Hog Ring Plier

Removal


NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Front Seat](#) (501-10A Front Seats, Removal and Installation).
2. Refer to: [Front Head Restraint Guide Sleeve](#) (501-10A Front Seats, Removal and Installation).
- 3.



E151148

- 4.




E100400


5. If equipped.



6.



7. If equipped.



8. If equipped.



9.



Installation

1. To install, reverse the removal procedure.
2. Use the General Equipment: [Hog Ring Plier](#)

