


Removal and Installation


Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Torque: 40 Nm




2. Torque: 3 Nm



E151230

- 3.



Installation

1. To install, reverse the removal procedure.

mcx30.com