



Removal and Installation

Special Tool(s)

	501-125 Remover, Grab Handle Cover
---	---------------------------------------

Removal

1. Use Special Service Tool: [501-125](#).



Installation

1. To install, reverse the removal procedure.
2. If the door is equipped with one touch up/down, perform the power door window initialization.

Refer to: [Power Door Window Initialization](#) (501-11 Glass, Frames and Mechanisms, General Procedures).