


Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Liftgate Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
2. Torque: 5 Nm



3.



Installation

1. To install, reverse the removal procedure.

mcx30.com