

Removal and Installation


Removal

NOTE: Removal steps in this procedure may contain installation details.


1. Refer to: [Rear Door Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
2. Torque: 8 Nm




3.



4. If equipped.



5.



Installation

1. To install, reverse the removal procedure.