

Removal and Installation

General Equipment

Blind Rivet Gun

Electric Drill


Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Second Row Double Seat Backrest Cover](#) (501-10B Second Row Seats, Removal and Installation).
2. Torque: 3 Nm




3. Torque: 3 Nm




- 4.



5. Use the General Equipments: [Electric Drill](#), [Blind Rivet Gun](#)



6. Torque: 40 Nm



Installation

1. To install, reverse the removal procedure.