

PREHEATING

Heater plugs: Removal - Refitting

13C

K9K

- ☐ Unscrew the heater plugs using a **10 mm** long socket connected to a universal joint or a **hinged wrench for heater plug**.
- ☐ Use a hose to unscrew the heater plugs completely.
- ☐ Remove the heater plugs.

REFITTING

I - REFITTING OPERATION

- ☐ Without tightening, fit the heater plugs using the hose.
- ☐ Torque tighten the **heater plugs (15 N.m)**.
- ☐ Connect the connector for each heater plug.

II - FINAL OPERATION

- ☐ Refit the engine cover.