

Diesel injection computer: Configuration

K9K, and 750 or 752 or 764 or 766 or 768

- ☐ To configure the computer, (see **MR 394 Fault finding, Diesel Injection, Configuration and programming**).