


Flow regulation solenoid valve: Removal - Refitting

K9K, and 764 or 772



112789

- ❑ The flow regulation solenoid valve (1) is integral with the high pressure pump.
- ❑ Replace the « high pressure pump - flow regulation solenoid valve » assembly in the event of a fault in the flow regulation solenoid valve (see **13B, Diesel injection, High pressure pump: Removal - Refitting**, page 13B-23) .