


Fuel vapour recirculation circuit: Operating diagram

D4F or F4R or K4J or K4M or M4R


OPERATING DIAGRAM OF THE CIRCUIT

F4R or K4J or K4M or M4R – D4F, and 740 or 742 or 764



- (1) Inlet manifold
- (2) Fuel vapour absorber bleed solenoid valve
- (3) Fuel vapour absorber
- (4) Tank
- (5) Breather

D4F, and 784



- (1) Inlet manifold
- (2) Fuel vapour absorber bleed solenoid valve
- (3) Fuel vapour absorber
- (4) Tank
- (5) Breather
- (6) Anti-return valve
- (7) Turbocharger
- (8) Air filter unit
- (9) Air filter box outlet air pipe