

STARTING - CHARGING
Charge circuit: Specifications

16A

D4F or F4R or K4J or K4M or K9K or M4R

ALTERNATOR SPECIFICATIONS

Engine	Alternator	Current strength
D4F	8200429898	90 A
	8200429905	120 A
K4J	8200323137	120 A
	8200459711	120 A
K4M	8200323137	120 A
	8200459711	120 A
M4R	7701065385	120 A
F4R	8200429905	120 A
K9K	8200390675	120 A
	8200390676	150 A