

Marks	Designations	Informations
1	Clip	
2	Front side air distribution duct	(see 61A, Heating, Front side air distribution duct: Removal - Refitting)
3	Dashboard cross member	
12	Bolt	
15	Clip	
17	Front air inlet duct	(see 61A, Heating, Front air inlet duct: Removal - Refitting)
18	A-pillar air distribution duct	(see 61A, Heating, Front footwell air distribution duct: Removal - Refitting)
20	Bolt	
21	Clip	
22	Front side air distribution duct	(see 61A, Heating, Front side air distribution duct: Removal - Refitting)
23	Distribution unit	(see 61A, Heating, Distribution unit: Removal - Refitting)

VALEO DISTRIBUTION UNIT

Marks	Designations	Informations
4	Front side air distribution duct	(see 61A, Heating, Front side air distribution duct: Removal - Refitting)
5	Clip	
6	Dashboard cross member	
7	A-pillar air distribution duct	(see 61A, Heating, Front footwell air distribution duct: Removal - Refitting)
8	Clip	
10	Bolt	
11	Distribution unit	(see 61A, Heating, Distribution unit: Removal - Refitting)
14	Front air inlet duct	(see 61A, Heating, Front air inlet duct: Removal - Refitting)
16	Front side air distribution duct	(see 61A, Heating, Front side air distribution duct: Removal - Refitting)
19	Clip	



Repair-30x02x08-02x50-1-3-1.xml



XSL version : 3.02 du 22/07/11

AIR FILTER: REMOVAL - REFITTING



Note, one or more warnings are present in this procedure



REMOVAL

1. REMOVAL OPERATION

