

Refit the differential.

3. FINAL OPERATION

Proceed in the reverse order to removal.



Repair-12x07x02x32-01x37-1-1-1.xml





XSL version : 3.02 du 22/07/11

mcx30.com

AUTOMATIC GEARBOX: LIST AND LOCATION OF COMPONENTS

ACTUATORS






144622

(1) Clutch actuator motors

(2) Computer integrating the actuator motors of the gear shift drums

SENSORS





(3) Gear engaged sensor

(4) Engine speed sensor of fourth gear


(5) Engine speed sensor of third gear

(6) Engine speed sensor of differential






144722



- (7) Gearbox breather
- (8) Gearbox filler plug
- (9) Gearbox drain plug

GEARBOX WIRING



144615