

■ use brake fluid which conforms to the Renault standard [Vehicle: Parts and consumables for the repair](#)
(04B, Consumables - Products),
■

■ check the brake fluid levels in the brake circuit and the bleeding device,

■ the braking regulation circuit must be free from all hydraulic and electrical faults,

check that the pressure of the bleeding device is between 1.5 bars and 2 bars.



Repair-13x03x01-02x60-1-11-1.xml



XSL version : 3.02 du 22/07/11

mcx30.com