



Repair-40x03x02x02-02x49-1-11-1.xml



XSL version : 3.02 du 22/07/11


mcx30.com

CIGARETTE LIGHTER: REMOVAL-REFITTING

REMOVAL

1. REMOVAL PREPARATION OPERATION


- Switch off the ignition.



Unclip the left-hand centre console trim(1) .



Remove the cigarette lighter(4) .



107727

Keep the plastic support unlocked at(5) .

Pull the cigarette lighter support at(6) .

Unclip the plastic support from the centre console upper panel.