

the ignition coil,

the ignition coil bolts.

Torque tighten the ignition coil bolts([see 11A, Top and front of engine, Cylinder head assembly: Exploded view](#)) .

Proceed in the reverse order to removal.



Repair-32x03x01x07-01x37-1-62-1.xml




XSL version : 3.02 du 22/07/11


mcx30.com

# COLOURCODE:IDENTIFICATION

## 1. EXAMPLE LOCATION OF THE VEHICLE IDENTIFICATION PLATE



## 2. EXAMPLE DETAIL OF THE VEHICLE IDENTIFICATION PLATE



19031

(1) Vehicle identification plate

(2) Paintwork reference number

Note:



For all additional information concerning vehicle identification, see the MR of the vehicle concerned , (01C, Vehicle: Identification).