

CONTROL - SIGNALS: PRECAUTIONS FOR REPAIR



Note, one or more warnings are present in this procedure



1. ROTARY SWITCH



CAUTION

Incorrect wheel alignment may damage the rotary switch.

During an operation on the steering column switch assembly, the wheels of the vehicle must be set straight ahead.



CAUTION

In order not to damage the rotary switch, do not turn the movable part of the rotary switch (except if adjusting).

To avoid damage, the rotary switch must be in the neutral position when refitting the steering wheel.



CAUTION

To ensure that the electronic systems operate correctly, do not damage the locking systems of the connectors.

In order not to damage the wiring harness, observe the original routing when refitting the steering column switch assembly.



Repair-30x04x03x40-02x60-1-1-1.xml

