



mcx30.com

CRUISE CONTROL - SPEED LIMITER: LIST AND LOCATION OF COMPONENTS

Equipment required
Diagnostic tool


1. LIST OF COMPONENTS

1- THE "CRUISE CONTROL" FUNCTION IS COMPOSED OF:

- a control switch
- steering column switches [Steering assembly: Exploded view](#)
- a brake pedal switch [Pedal assembly: Exploded view](#)

2. LOCATION OF COMPONENTS

1- CONTROL SWITCH




Apply the before / after repair procedure using the Diagnostic tool [Diagnostic tool : Use](#) :

-Computer concerned by the Before / After repair procedure:

"Injection computer" ,

-Component controlled by this computer concerned by the Before / After repair procedure:

"Cruise control and speed limiter control" .



The steering column switches cannot be separated from the steering wheel.

In the event of any faults, replace the steering wheel [Steering assembly: Exploded view](#) .

3- BRAKE PEDAL SWITCH