





Earth stud on the left-hand rear quarter panel lining(12) .




Earth stud on the right-hand rear quarter panel lining(13) .



REMOVAL

1. REMOVAL PREPARATION OPERATION


- Switch off the ignition.



- Unclip the left-hand centre console trim(1).

- Disconnect the electrical accessories socket connector.

2. REMOVAL OPERATION



Unclip the clips from the electrical accessories socket at(2) .



Remove the electrical accessories socket.

REFITTING



Proceed in the reverse order to removal.