

Locate the earths located near to the weld area [Earths on body: List and location of components](#) .

3)SPECIAL NOTES ON MATING



CAUTION

If the mating faces of the parts to be welded are not accessible, use a GMAW plug weld in place of the original electrical resistance weld [Connections by arc welding under shielding gas: Description](#) (MR 400, 40C, Gas metal arc welded connections (GMAW)).



Repair-40x02x08-02x49-1-9-1.xml



XSL version : 3.02 du 22/07/11

