




Repair-11x04x06x09-01x58-1-43-1.xml



XSL version : 3.02 du 22/07/11

mcx30.com

FUEL TANK ASSEMBLY: EXPLODED VIEW



[Illustration key: Description](#) .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques:[Tightening torques: General information](#) .

Marks	Designations	Informations
1	Fuel return pipe	
2	Fuel supply pipe	
3	Fuel level sensor module ring	(Mot. 1397)
4	Fuel filler cap	
5	Fuel level sensor module	(see 19C, Tank, Fuel level sensor module: Removal - Refitting)
6	Fuel level sensor module seal	
7	Fuel tank	(see 19C, Tank, Fuel tank: Removal - Refitting)
8	Fuel steam pipe	