




157962

Make a superimposed connection [Partial replacement connections by overlapping: Description](#) [Partial replacement connections by overlapping: Description](#) (MR 400, 40E, Partial replacement connections).



Repair-40x09x02x10-02x49-1-8-1.xml



XSL version : 3.02 du 22/07/11

REAR LIGHTING: LIST AND LOCATION OF COMPONENTS

Location and specifications (tightening torques, parts always to be replaced, etc.) [\(see 81A, Rear lighting, Rear signals - lighting assembly: Exploded view\)](#) .

1. LIST OF COMPONENTS

1- THE "REAR LIGHTING" EQUIPMENT CONSISTS OF:

- rear lights on wing,
- rear opening element lights,
- rear light bulbs,
- an high level brake light.

2. LOCATION OF COMPONENTS

1- REAR LIGHT ON WING

Open the tailgate.

Remove the rear bumper side trim [Rear bumper assembly: Exploded view](#) .



Remove [\(see 81A, Rear lighting, Rear signals - lighting assembly: Exploded view\)](#) :

- the rear light on wing screws,
- the rear light on wing nut,
- the rear light on wing.

Disconnect the rear light on wing connector.

2- REAR OPENING ELEMENT LIGHT

Open the tailgate.

Remove the rear opening element trim [Rear opening element trim: Removal - Refitting](#) .

Remove [\(see 81A, Rear lighting, Rear signals - lighting assembly: Exploded view\)](#) :



the rear opening element light nuts,



the rear opening element light.

Unclip the bulb holder.

3- REAR LIGHT BULBS

The rear opening element light bulbs can be replaced without removing the rear light (accessible by the rear opening element trim flap).

The rear light on wing bulbs are to be replaced by removing the rear light and unclipping the bulbs support plate.

To replace any bulbs [\(see 81A, Rear lighting, Rear signals - lighting assembly: Exploded view\)](#) .

4- HIGH LEVEL BRAKE LIGHT

Remove [Exterior rear opening element assembly: Exploded view](#) :



the rear screen side trims,



the rear opening element spoiler.

Disconnect the high level brake light connector.

Remove [\(see 81A, Rear lighting, Rear signals - lighting assembly: Exploded view\)](#) :



the high level brake light screws,



the high level brake light.