





Repair-40x09x03-02x49-1-2-1.xml



REAR SIDE WINDOW MECHANISM ASSEMBLY: EXPLODED VIEW


ELECTRIC WINDOW(Electrical)



[Illustration key: Description](#) .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Exterior weatherstrip of rear side opening element window	
2	Rear side opening window	
3	Glass run channel of rear side opening element	
4	Clips	
5	Rear side opening element	Rear side opening element: Removal - Refitting
6	Interior weatherstrip of rear side opening element window	
7	Nuts of rear side opening element window winder mechanism	
8	Bolts of rear side opening element window winder mechanism	
9	Nuts of rear side opening element window winder mechanism	



[Illustration key: Description](#) .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Rear side opening element	Rear side opening element: Removal - Refitting
2	Interior weatherstrip of rear side opening element window	
3	Nuts of rear side opening element window winder mechanism	
4	Rear window winder handle	
5	Nut of rear side opening element window winder mechanism	
6	Bolts of rear side opening element window winder mechanism	
7	Glass run channel of rear side opening element	
8	Clips	
9	Rear side opening window	
10	Exterior weatherstrip of rear side opening element window	