

12	Headlining rear clips	
13	Roof soundproofing	

KSL version : 3.02 du 22/07/11



Repair-70x02x04x01-02x50-1-4-1.xml



mcx30.com

ROTARY SWITCH: ADJUSTMENT



Note, one or more warnings are present in this procedure



WARNING

■ To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:



■ [\(see 84A, Control - Signals, Control - Signals: Precautions for repair\)](#) ,

■ [Vehicle: Precautions for the repair](#) .

This method is used to put the rotary switch in the neutral position.

1. PRELIMINARY CONDITIONS FOR THE ADJUSTMENTS



The wheels are set straight ahead.



The rotary switch is refitted on the steering column.



The steering wheel is removed.

2. ADJUSTMENT

Note:



Certain rotary switch models are equipped with a locking device.

To perform the adjustment, it is essential to unlock the rotary switch when handling.

