

poorly performed repair operations.

2- REPAIRING THE SEALING



Sealing repair consists of:

-
- individually testing the possible causes of the water ingress detected.
- stopping the identified cause.
- checking the repair.
- continue the checking cycle to ensure that there is no other ingress of water.
- confirm the repair through a checking cycle of the zone.




Repair-60x01x01-02x01-1-1-1.xml



XSL version : 3.02 du 22/07/11

1. CENTRAL STRUCTURE



112110