

BRAKING CONTROL ASSEMBLY: EXPLODED VIEW




Illustration key: Description .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques: [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Brake fluid reservoir	
2	Brake fluid reservoir pin	
3	Master cylinder seal on brake fluid reservoir side	
4	Brake pipe between master cylinder and hydraulic unit	
5	Bleed screw	
6	Brake servo heightener	
7	Seal between brake assist and bulkhead	
8	Master cylinder	(see 37A, Mechanical component controls, Master cylinder: Removal - Refitting)
9	Bleed screw	
10	Brake pipe between master cylinder and hydraulic unit	
11	Brake pipe between master cylinder and hydraulic unit	
12	Hose between brake fluid tank and brake servo	
13	Connecting pipe between the brake fluid reservoirs	
14	Brake fluid reservoir cap	
15	Brake fluid remote reservoir	
16	Rigid brake pipe between hydraulic unit and front left brake hose	
17	Rigid brake pipe between hydraulic unit and intermediate union	
18	Rigid brake pipe between hydraulic unit and front left brake hose	
19	Rigid brake pipe between hydraulic unit and intermediate union	
20	Nut	
21	Brake pipe between master cylinder and hydraulic unit	
22	Brake pipe between master cylinder and hydraulic unit	
23	Brake pipe union	
24	Nut	
25	Supply hydraulic hose	
26	Nut	
27	Bolt	

